


**KitchenAid®**

# COOKTOP PARTS

For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)

30" Freestanding  
Gas Range  
DESIGNER STYLE  
Convection Oven



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP PARTS


For Models:KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9		Cover, Light	18		Cap, Vent
	LIT9755235	Installation Instructions		9751327	White		9751271GW	White
	LIT9754288	Use & Care Guide		9751632	Black		9751271GB	Black
	LIT9754241	Tech Sheet		9753320	Biscuit	19	9751366	Cap, Vent
	LIT9754372	Wiring Diagram	10		Backsplash	20	9751984	Fuse, Bi-Metal
	LIT9752775	Template, Anti-Tip		9781896GB	Black	22	9752006	Thermostat, Fixed
	LIT3191638	Safer Cooking Tips		9781896GW	White	23		Bumper, Rubber
	LIT9753848	LP Installation Instructions		9781896GC	Biscuit		9750969	White
2	9754102	Gasket, Cooktop	11		Bezel, Burner		9780771	Black
3		Trim, Cooktop (Right Hand)			Mouse Gray	26	9751664	Cover, Backsplash
	9751275PW	White		9753601GS	6K RF-LR	27		Endcap, Backsplash (Right Hand)
	9751275PB	Black		9753602GS	12K RR		9781885FB	Black
	9751275PC	Biscuit (Left Hand)		9753600GS	14K LF		9781885FW	White
	9751276PW	White			Black		9781885FC	Biscuit (Left Hand)
	9751276PB	Black		9753601GB	6K RF-LR		9781884FB	Black
	9751276PC	Biscuit		9753602GB	12K RR		9781884FW	White
4	9781982	Gasket, Cooktop		9753600GB	14K LF		9781884FC	Biscuit
5	9754197	Support, Burner	13		Grate, 2 Burner	28		Glass, Backsplash
6	9751629	Bracket, Pivot		9753616GS	Mouse Gray		9753910CW	White
	9752003	Washer, Pivot		9753616GB	Black		9753910CB	Black
7		Cooktop, Glass	15	9752638	Pad, Grate (4)		9753910CC	Biscuit
	9753606CO	Opaque White			Mouse Gray		9753292	Clear Glass (Stainless Model)
	9753606CB	Black		3191899	6K RF-LR	29	9781490	Seal
	9753606CT	Biscuit		3191905	12K RR	30	9754071	Panel, Backguard (Stainless)
8	9753691	Bracket, Support		9753939GS	14K LF			
					Black	32	9780265	Screw, 10-16 x 3/8
				3191898	6K RF-LR	33	3149333	Screw, 10-16 x 1/2
				3191904	12K RR	34	9751871	Screw, 10-16 x 1
				9753939GB	14K LF			
			17	3411196	Thermo-Disc			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COOKTOP BURNER PARTS

For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Burner Base W/Orifices
	9782447	6K RF-LR
	9782448	12K RR
	9782449	14K LF
2	9753610	Tubing, Burner(RF)
3	9753611	Tubing, Burner(RR)
4	9753608	Tubing, Burner(LF)
5	9753609	Tubing, Burner(LR)
6	9754148	Tubing, Manifold


Illus. No.	Part No.	DESCRIPTION
7		Valve, Burner
	9755345	6K RF-LR Red Stem
	9755344	12K RR Black Stem
	9755405	14K LF Plain Stem
8	8523704	Bolt, Gas Valve(4)
9	9755451	Spark Switch & Harness Assembly
11		Manifold
	9782470	Left Hand
	9782471	Right Hand
13	9782116	Electrode

Illus. No.	Part No.	DESCRIPTION
16		Orifice, Burner
	9753928	6K RF-LR
	9753929	12K RR
	9753930	14K LF
18	9751854	Tubing, Flex
19		Head, Burner
	4455979	6K RF-LR
	4455981	12K RR
	4455849	14K LF
	9754136	Pad, Burner Ring
20	8281147	Screw, 8-18 x 5/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models:KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)




Illus. No.	Part No.	DESCRIPTION
1	9782418CW	Console, Glass White
	9782418CB	Black
	9782418CC	Biscuit
2	9782430	Board, Display
3	9780271	Screw, 8-18 x 1/4
4		End Cap Right Hand
	9751280FW	White
	9751280FB	Black
	9751280FC	Biscuit
		Left Hand
	9751279FW	White
	9751279FB	Black
	9751279FC	Biscuit
7	9780265	Screw, 10-16 x 3/8
8		Knobs, Control
	9751199FW	White
	9751199FF	Black
	9751199FC	Biscuit
10	9782435	Board, Power
11	9755021	Shield, Control Panel
23	3191387	Seal, Switch
24	9781488	Spacer, Bottom Trim

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS

For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR AND DRAWER PARTS


For Models:KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION
2		Trim, Door-Left
	9782003PW	White
	9782003PB	Black
	9782003PC	Biscuit
3		Trim, Door-Right
	9782004PW	White
	9782004PB	Black
	9782004PC	Biscuit
4		Trim, Door Bottom
	9781209PW	White
	9781209PB	Black
	9781209PC	Biscuit
5		Glass, Door
	9781627PW	White
	9781627PB	Black
	9781627PC	Biscuit
	9754041	Stainless
6		Vent, Door
	9753498GW	White
	9753498GB	Black
	9753498GC	Biscuit
	9781490	Seal, Door
	9781659	Gasket, Vent
8		Handle, Door
	9780523PW	White
	9780523PB	Black
	9780523PC	Biscuit
9	9781449	Gasket, Door Glass
10	9782033	Hinge, Door R or L
12	9781602	Frame, Window
13	9781586	Shield Door
14	9780771	Bumper, Rubber
15	9781593	Glass, Door (2)
16	9755177	Seal, Glass
18	9754006	Insulation
19	9781600GM	Liner, Door
20	9780583	Drawer & Roller
	9750257	For Stn. Steel MDL
21	9750169	Bracket, Drawer
22	423713	Support, Roller
23	9750676	Retainer, Door
24		Front, Drawer
	9782108PW	White
	9782108PB	Black
	9782108PC	Biscuit
	9782109PB	For Stn.Steel MDL
25	9750693	Heat, Channel
27	90296	Clip
28	9781502	Retainer, Glass
29	9780265	Screw
30	3400075	Screw
31	9781072	Screw
33		Stainless Model
34	9750614PB	Trim, Drawer-Top
35	9753329	Spacer
36	9754062	Panel, Drawer
37	9750613PB	Trim, Drawer-Btm

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9**  
**(White) (Biscuit) (Stainless Steel) (Black)**

**For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9**  
**(White) (Biscuit) (Stainless Steel) (Black)**



**FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST**

# OVEN CHASSIS PARTS

For Models:KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION
1	8522426	Module, Spark
2	9750514GM	Chassis, Front
5	9753335GM	Oven Liner
6	9755179	Gasket Oven
7		Oven, Side L or R
	9781907PW	White
	9781907PB	Black
	9781907PC	Biscuit
8	9780664	Shield, Insulation
9	9751789	Fan Duct, Side
10	9782329	Duct
11	9752637	Burner Box
12	9752735	Retainer, Insulation
13	9751653	Duct, Top
14	9751060	Support, Fan
15	9750223	Drawer Rail, Left
	9750224	Drawer Rail, Right
16	9751020	Motor, Fan
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9782005	Hinge, Door L or R
21	9782051	Shield, Drawer
22	9782050	Plate, Reflectance
23	9780265	Screw, 10–16 x 3/8
24	9782326	Shield, Heat
25	9751592	Vent Tube
29	9755192	Door Switch
30	9751808	Screw, 8–18 x 1
31	9780270	Screw, 8–18 x 3/8


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# BROILER & OVEN BURNER PARTS

For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)


Illus. No.	Part No.	DESCRIPTION
1	9752737	Shield, Oven (2)
2	9752738	Flame Shield, Bake
3	9752922	Burner, Broiler
4	9751367	Burner, Bake
6	9782065	Ignitor,
7	9752858	Bracket, Broil Shooter
8	9752736GM	Pan, Oven Bottom
9	9782061	Tubing, Broil
10	9752698	Valve & Regulator Assembly
11	776593	Screw, 1/4-20x1/2
12	9781015	Tubing, Valve To Regulator
13	9752734	Pan Support, Bake
14	9751600	Bracket, Bake
15	9751203	Nut #18 5/8
16	9752920	Coverbox (Broiler Tubing)
17	9752716	Orifice #54
18	9751643	Screw, 10-24 x 3/8
19	9780265	Screw, 10-16 x 3/8



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9781543	Assembly, Fan
2	9780272	Screw, 10-16 x 1/2
9	9751904GM	Baffle, Convection
	9780270	Screw, (2) 8 x 3/8
10	4167277	Lock-Nut, Cvr.Jack
11	4167266	Jack Cover
12	305289	Gasket


Illus. No.	Part No.	DESCRIPTION
13	4173575	Receptacle, Probe
14	3179672	Spacer, Tubing
15	8935	Bulb, Oven
16	9781050	Light, Socket
17	3150144	Probe
18	420104GM	Grill, Broiler

Illus. No.	Part No.	DESCRIPTION
19	420101GM	Pan, Broiler
20	9750827	Rack, Roasting
21	9750823	Rack, Standard (3)
22	9782081	Sensor
23	9781049	Lens, Light
24	3184533	Gasket, Lens
25	9780265	Screw, 8-32 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REAR CHASSIS PARTS

For Models:KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)



Illus. No.	Part No.	DESCRIPTION
1	9751051	Back, Chassis
2	340184	Screw, 10-16 x 1.5
3	9751353	Panel, Rear Cover
4	423247	Screw, 10-16 x 3/8
5	9755444	Suppressor, Trans
6	9751500	Bracket, Regulator Valve
7	9755001	Oven Lock Assy.
8	112432	Nut
12	9754291	Switch, Interlock
13	9750887	Screw, 4-40 x 1
14	9750888	Nut (2)
15	9750523	Rod, Lock
17	258076	Block, Terminal
18	98884	Screw, 10-16 x 1
19	9780265	Screw, 10-16 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MISCELLANEOUS PARTS

For Models:KGRT607HWH9, KGRT607HBT9, KGRT607HBS9, KGRT607HBL9  
(White) (Biscuit) (Stainless Steel) (Black)

Illus. No.	Part No.	DESCRIPTION
<b><u>SPLICING WIRES--25FT. LENGTH</u></b>		
242828	Wire, Black	12 Ga. 150°c
242820	Wire, Black	14 Ga. 150°c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242829	Wire, Red	12 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242826	Wire, White	14 Ga. 150°c
242827	Wire, Yellow	14 Ga. 150°c
242832	Wire, Yellow	14 Ga. 200°c
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>		
72017	White	
72107	Almond	
511873	White Porcelain	(2 Oz.)
4392899	Biscuit	

Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>		
350930	White	
350956	Almond	
285006	Superior Black	
206922	Primer (White)	
4392901	Biscuit	
<b><u>PAINT, BULK (1 qt.)</u></b>		
799344	White (Uncut)	
978883	Almond (Uncut)	
4392900	Biscuit (Uncut)	
<b><u>REFINISHING MATERIAL</u></b>		
799832	Kit, Porcelain Repair	(White)
242756	Touch-Up	Self-Clean (1/2 Pt.)
<b><u>INSULATION</u></b>		
9754004	Insulation, Wrap	
9754011	Insulation, Rear	
9754005	Insulation, Bottom	
9754301	Insulation, Flue	Cut Out
<b><u>CLEANER, COOKTOP</u></b>		
9753543	Glass Cleaner	
3183488	Scraper	
<b><u>ACCESSORIES</u></b>		
241430	Foil, Aluminum	Oven (18" X 25')

Illus. No.	Part No.	DESCRIPTION
<b><u>CONVERSION KIT</u></b>		
9753604	Gas Conversion Kit	LP
9752717	Natural	
<b><u>LUBRICANT</u></b>		
261582	Grease	
<b><u>ANTI-TIP KIT</u></b>		
9751745	Anti-Tip Kit	
<b><u>WIRING HARNESS PARTS</u></b>		
9782465	Harness, Wire	(Main Harness)
9782460	Harness, Wire	(Neutral Gas)
9782443	Harness, Wire	(Pwr Brd to Dsply)
9782454	Harness, Wire	(Cooktop-Dual)
9782466	Harness, Wire	(Fan/Bms)
9755193	Harness, Wire	(Oven Door)
9753374	Harness, Wire	(Dual Oven Light)
9755024	Harness, Wire	(M.Probe S/I)
9754366	Harness, Wire	(Bake Jumper)
20082084	Tie, Wire	
9781555	Clip, Wire	
9782111	Wrap, Tie	
9751868	Grommet Harness (2)	
9782344	Wire, Jumper	(Spark Module)
9781055	Power Cord	
3196520	Clip, Wire	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST